

# **Weistec M157/M278 ENGINE**

## **High Flow Air Filters Installation Guide**

---



- 2011+ S63 AMG
- 2012+ S550
- 2013+ ML63 AMG
- 2012+ CLS63 AMG 2012+ CLS63 AMG
- 2012+ CLS550
- 2012+ E63 AMG (Sedan and Wagon)
- 2012+ E550 (Sedan and Wagon)
- 2011+ CL63 AMG
- 2012+ CL550
- 2013+ SL63 AMG
- 2013+ SL550 AMG

---

## **WEISTEC M157/M278 High Flow Air Filters**

Thank you for your purchase of the Weistec M157/M278 High Flow Air Filters for the Mercedes AMG 63 and 550 Biturbo vehicles. Please follow all directions, and keep a clean work space when commencing installation.

### **Tools Required**

- Flat Head Screw Driver
- T25 3/8" Bit
- 3/8" Drive Ratchet

I. High Flow Air Filter Install

- a. Remove Engine covers by gently pulling them up.



- b. Remove Air inlet tubes by pulling them off the radiator shroud then off the airboxes



- c. Unplug the harnesses from the two sensors on each air box by pulling the grey locking tab out and then pressing it to unlock the connector from the sensor and gently pull the connector off.



- d. Loosen clamps on airboxes using a flat head screw driver



e. Remove airboxes from vehicle and loosen the four screws circled below



- f. Separate airboxes to reveal the air filters. At this point, pull out the OEM air filter and install the Weistec M156/M278 High Flow Air Filters.



- g. Perform the above steps in reverse order to complete installation.